

N.E. 1/4
SECTION 36. T.7N., R.2W., S.L.B.&M.

TOWN OF PLEASANT VIEW, FARR WEST & HARRISVILLE DISTRICTS

TAXING UNITS: 01, 02, 11, 23, 45, 63, 17

SCALE 1"=200'

SEE P. 18-2

PREFIX 18-041
ALSO SEE P. 41-23

41-1

